



NOTES:

- 1) USE ROMAC INDUSTRIES, INC. STYLE "CB" DUCTILE IRON SEWER SADDLE, OR APPROVED EQUIVALENT.
- 2) CORE DRILL AN APPROPRIATELY SIZED HOLE IN EXISTING PIPE TO ACCOMPLISH THE TAP.
- 3) INSTALL SADDLE IN ACCORDANCE WITH SADDLE MANUFACTURERS INSTRUCTION.



City of Lake Oswego
Engineering Division

Erica Rooney, P.E. City Engineer

**WASTEWATER STRAP-ON
TYPE TAPPING TEE**

WW4-01

EFFECTIVE DATE: JANUARY 1, 2018

NOT TO SCALE

DRAWING NUMBER